
IODD MINI Password Reset Guide

⚠️ WARNING: DATA LOSS HAZARD

Performing this password reset will initialize the internal SSD. All existing data on the IODD MINI will be permanently erased. Please proceed only if you have a backup or do not mind losing the data.

Step 1: Install Reset Firmware

1. Download the password reset firmware.
2. Run `iodd_firm_upd-0.1.0.11-Del-Password.exe`.
3. Complete the firmware update process.

Step 2: Clear the Password

1. Once the update is finished, **disconnect** and then **reconnect** the device to your computer.
2. Wait for the LCD screen to initialize.
3. When the password prompt appears, **repeatedly press the Menu button** (more than 300 times) until the message "**Password is deleted**" is displayed on the screen.

Step 3: Restore Standard Firmware

After the password has been successfully deleted, you must reinstall the standard operating firmware:

1. Download the general firmware.
2. Run `iodd_firm_upd-0.1.0.13.exe` to return the device to its normal operating state.
